



Obtuse screws x 28
Wooden pins x 14
Long screws x 8
Short screws x 12



Insert the wooden pins (14 pcs) to each hole in the ready-made leg parts.



Adjust the boards. The board with the hole must be in the middle.



Turn the table upside down and adjust the shorter board with a hole in the middle like in the picture and attach it with the long screws (8 pcs). Attach the legs with obtuse screws (28 pcs).



Install the diagonal leg parts and attach them with long screws (8 pcs) like in the picture.



Obtuse screws x 12
Wooden pins x 6



Insert the wooden pins (6 pcs) to each hole in the ready-made leg parts.



Adjust the boards.



Turn the bench upside down. Attach the boards with screws (12 pcs).



Use the tool in the plastic bag when tightening the screws and bolts – use an electric screwdriver only, if You are a professional -we cannot reimburse the damages caused by using an electric screwdriver. Remember to re-oil wooden tables and benches with good quality wood oil regularly, depending on the weather and moisture conditions. Also check the screws regularly, tighten when needed. Store in a cool and dry place, clean thoroughly before storing.

For more info, check: www.ecofurn.eu